


NORVIK STOVE PARTS LIST



No	NAME	MATERIAL
01	Base	Cast Iron
02	Right Side	Cast Iron
03	Left Side	Cast Iron
04	Back	Cast Iron
05	Door Frame	Cast Iron
06	Back Plate	Cast Iron
07	Top	Cast Iron
08	Outer Grate	Cast Iron
09	Inner Grate	Cast Iron
10	Baffle 1	Cast Iron
11	Knob	Stainless Steel
11-A	Slider Bar	Stainless Steel
11-B	Slider Plate	Steel
12	Steel Riddle Bar	Stainless Steel
13	Spring Washer	Steel
14	Baffle 2	Cast Iron
15	Baffle 3	Cast Iron
16	Inner Right Side Brick	Cast Iron
17	Inner Left Side Brick	Cast Iron
18	Steel Slider	Steel
19	Door Catch	Steel
20	Coal Guard	Cast Iron
21	Riddle Bar Connector	Steel
22	Door Glass	Heat Resistant Glass
23	Air Cover Plate	Cast Iron
24	Door	Cast Iron
25	Door Spinner	Cast Iron
26	Tin Ashpan	Tinplate
27	Flue Collar	Cast Iron
28	Door Handle Knob	Stainless Steel
29	Door Handle	Stainless Steel
30	Legs	Cast Iron
31	Opening Tool	Cast Iron
32	Bottom Cover Plate	Cast Iron
33	Flue Strip	Cast Iron
34	Flue Cover	Cast Iron