
TITUS STOVE PARTS LIST



No	DESCRIPTION
01	Airwash Control
02	Door
03	Trim
04	Door Handle
05	Grate Lever Primary Air Control
06	Baffle Support Pin
07	Upper Baffle Plate
08	Baffle Plate
09	Tertiary Air Inlets
10	Firebox Liner
11	Fuel Retainer
12	Grate
13	Ashpan
14	Multi Tool

